

AdBlue Emulator V4 NOx


Attention! Always connect the ground cable first! Otherwise, you can burn the emulator module or damage the SCR / NOx module of the truck!

AdBlue Emulator V4 NOx is compatible with DAF trucks of LF (Grundfos) and the XF series. This is the installation manual for DAF LF (Grundfos) trucks – EURO 4, EURO 5, and EURO 5 EEV versions. Before installing AdBlue Emulator V4 NOx on DAF LF (Grundfos) truck please make sure that you have the emulator programmed to DAF LF (Grundfos) program. You can order a pre-programmed emulator or you can purchase an AdBlue Emulator V4 programmer designed for V4 type emulators and change the program yourself.


AdBlue Emulator V4 NOx installation steps

ATTENTION! IF YOU HAVE FAULTS ON THE TRUCK YOU MUST MAKE ECU RESET TO FACTORY SETTINGS BY DAVIE OR ANY COMPATIBLE CHIP TUNING DEVICE!!! IF THERE ARE NO FAULTS THERE'S NO NEED TO MAKE A RESET.


Please locate the junction box under the hood of your DAF LF truck (same for EURO 4 / EURO 5 and EURO 5 EEV versions).




Locate this particular plug as shown and remove it (DAF LF EURO 4 / EURO 5 version).



To connect the AdBlue emulator we need to use these wires for CAN LOW, CAN HIGH, and +30 connection (DAF LF EURO 4 / EURO 5 version).




GND and other connections for AdBlue emulator (DAF LF EURO 4 / EURO 5 version).



Please remove these fuses from the fuse box (DAF LF EURO 4 / EURO 5 version).




Check your fuse map to avoid any mistakes (DAF LF EURO 4 / EURO 5 version).




DAF LF EURO 5 EEV version


Locate this plug and use it to connect the AdBlue emulator (DAF LF EURO 5 + EEV version).



Connect AdBlue emulator CAN HIGH, CAN LOW, and +30 wires to corresponding pins (DAF LF EURO 5 + EEV version).



Check your fuse map to avoid any mistakes (DAF LF EURO 5 + EEV version).



Remove these fuses from the fusebox (DAF LF EURO 5 + EEV version).



Attention! AdBlue emulators are illegal in some countries. You should check the local laws or laws of those countries that you might cross with your vehicle. AdBlue emulator alters the SCR system thus making the vehicle produce higher exhaust gas emissions. EURO 6 and EURO 5 vehicles equipped with AdBlue emulator devices will no longer match those EURO standards. Our AdBlue emulators are designed for countries where environmental rules are less strict, and there are no requirements for vehicles to satisfy EURO 6 or EURO 5 regulations. By purchasing any AdBlue emulator, you assume full responsibility for the use of the device. It's your personal decision to use an emulator or not. We will not accept any liability for any consequences associated with the usage of AdBlue emulator devices.