


# AdBlue Emulator V4 EVO installation manual for Volvo FH4/FM4 EURO 5 trucks

AdBlue Emulator V4 EVO FH4 EURO 5 is compatible only with Volvo FH4/FM4 EURO 5 trucks. This installation manual describes the whole process of AdBlue Emulator device installation on compatible Volvo FH4/FM4 EURO 5 vehicles. We highly recommend you to delete all DTC (Diagnostic Trouble Codes) errors from OBD (On-Board Diagnostics) system on your truck. The best option is to use the original Volvo diagnostic scanner. Also, it is recommended to check the OBD system after installation of AdBlue Emulator module because there might be errors related to installation procedures.


**Vehicle preparation!** To make sure that the emulator works as intended, you would need to launch active DPF regeneration before installing the emulator. To do that, you need to connect the vehicle to a diagnostics system (original Volvo or TEXA) and activate the regeneration function.

Connection diagram. Attention! Pay attention to the emulator sticker; colors of wires may vary.






Connector location





## Step 1: XC203 wire connections




1. Turn off the ignition.
2. Find the XC203 connector (refer to the images above)
3. Connect the following wires: Yellow (emulator CAN1 High) to wire 7004 (truck XC203, pin 1), Green (emulator CAN1 Low) to wire 7005 (truck XC203, pin 2), Red (emulator positive) to wire 2020 (truck XC203, pin 26)



Pin No.:	Circuit function	Wiring No.:
1	Backbone 1 high	7004
2	Backbone 1 low	7005
26	Ignition signal	2020

## Step 2: XC213 wire connections

1. Find the XC213 connector (refer to the images on the previous page)
2. Connect the following wires: Brown (emulator ground) to wire 1 (truck XC213, pin 7)




Pin No.:	Circuit function	Wiring No.:
7	Ground	1

### Step 3: XC302 wire connections

1. Find the XC302 connector (refer to the images on the previous page)
2. Connect the following wires: Gray (emulator CAN2 High) to wire 7036 (truck XC302, pin 3), Orange (emulator CAN2 Low) to wire 7037 (truck XC302, pin 6)

Pin No.:	Circuit function	Wiring No.:
3	Powertrain high	7036
6	Powertrain low	7037




### Step 4: Disabling NOx and ACM modules

1. Find the A174 connector on the ACM module
2. Find the CCIOM module

Location of the CCIOM and ACM modules:








## Disabling the ACM




1. Cut the wire on pin 3 of the A174 connector
2. Isolate the wire from both sides and plug the connector back in place

## Disabling the NOx

Find the X1 plug.



Cut the wire on the 6th pin on the X1 plug.





**Attention!** AdBlue emulators are illegal in some countries. You should check your local laws or laws of those countries that you might cross with your vehicle. AdBlue emulator alters SCR system thus makes the vehicle to produce higher exhaust gas emissions. EURO 6 and EURO 5 vehicles equipped with AdBlue emulator device will no longer match those EURO standards. Our AdBlue emulators designed for countries where environmental rules are less strict, and there are no requirements for vehicles to satisfy EURO 6 or EURO 5 regulations. By purchasing any AdBlue emulator, you assume full responsibility for the use of the device. It's your personal decision to use an emulator or not. We will not accept any liability for any consequences associated with usage of AdBlue emulator devices.